

D-Link Quick Installation Guide



DGE-528T
Gigabit Ethernet
PCI Adapter

Check Your Package Contents



- DGE-528T Gigabit Ethernet PCI Adapter



- CD with Manual and Drivers

If any of the above items are missing, please contact your reseller.

The DGE-528T supports drivers for the following operating systems:

Microsoft Windows 98SE/ME	Microsoft Windows Vista x64
Microsoft Windows NT4.0	Linux 2.4/2.6
Microsoft Windows 2000	Macintosh 10.2.X
Microsoft Windows 2003	Netware Server
Microsoft Windows XP	Netware DOS ODI Client
Microsoft Windows XP x64	NDIS2
Microsoft Windows Vista x86	FreeBSD

For Microsoft Windows


DO NOT insert the DGE-528T into the computer's PCI slot before installing the drivers.

1

Installing the DGE-528T Drivers

- Turn **ON** the computer.
- Insert the **driver CD**, which is included with the DGE-528T, into the CD-ROM drive.

The following window will appear.




Click "Install Drivers".

For **Windows XP64bit**, **Windows 2003**, **Windows Vista x86** and **Vista x64** users, this screen will be displayed.



Click OK


For **Windows 98SE** and **Windows ME** users, this screen will be displayed.



Click Yes

Next, TURN OFF the computer and unplug the power cord.

2 Installing the DGE-528T into the computer's PCI slot



Caution: To avoid damage caused by static electricity, make sure to properly ground yourself by first touching a metal part of your computer to discharge any static electricity before working with the DGE-528T Ethernet Adapter.


- **Turn off** your computer and **unplug** the power cord.
- **Remove** the back cover of your computer. (Refer to your computer's manual if needed.)
- **Locate** an available PCI slot. PCI slots are usually white or cream colored.
- **Remove** the backplate (the small piece of metal that covers the opening for the PCI card on the back cover that you just removed.)
- **Insert** the DGE-528T carefully and firmly into the PCI slot.
- **Secure** the DGE-528T with the screw from the backplate.
- **Replace** your computer's cover.

3

Finishing the Installation

TURN ON the computer.

For **Windows 98SE** and **Windows ME** users, the following screen will appear.




Click Yes, to restart the computer.

4

Checking the Installation

Go to:

START>CONTROL PANEL>SYSTEM>HARDWARE> DEVICE MANAGER.



To check that the installation of the **DGE-528T** was successful, scroll down and click on **"Network Adapters."**

You have a successful installation when **"D-Link DGE-528T"** appears (with no errors) as shown at left.