

<<<To EOS 7D Users Updating the Camera Firmware to Version 2.x.x or later>>>

This manual is for the EOS 7D installed with firmware version 2.0.0 or later.

Please refer to the pages below for further information about the new functions added by firmware version 2.x.x.

- Setting the zone/daylight saving time (p.43-44)
- Maximum burst during continuous shooting (p.61)
- Setting the maximum ISO Auto (p.65)
- Registering or changing the file name (p.82-83)
- Sound recording manual adjustment (p.162)
- Jump through Images (Jump display) by image rating (p.170)
- Setting ratings (p.173-174)
- Quick Control during playback (p.175-176)
- Processing RAW images with the camera (p.192-196)
- Resizing JPEG images (p.197-198)
- GPS device settings (p.259)

[Cautions for Using Software]

- To obtain ImageBrowser EX (p.282), download the ImageBrowser EX installer from Canon's Web site and perform installation.
- After updating the camera firmware, please also update EOS Utility to version 2.11.4 or later from Canon's Web site.

(The compatibility between the older version of EOS Utility on the provided CD-ROM, and the EOS 7D with firmware updated to version 2.x.x. is not guaranteed.)

- When using each software, confirm the latest computer hardware requirements on Canon's Web site.

[Cautions for Using Accessories]

- When using the Wireless File Transmitter WFT-E5 with the EOS 7D updated to firmware version 2.x.x, please also update the WFT-E5's firmware.
- When using the GPS Receiver GP-E2 with the EOS 7D, restrictions will apply to certain functions. For details, refer to the GPS Receiver GP-E2 Instruction Manual.